

Installation Guide

BL-554 Bluetooth USB Adapter in Windows2000

Version: 1.0



BL-554 Bluetooth USB adaptor Installation

This section will give you all the information that is needed to install your Brain Boxes Bluetooth USB Hardware into your computer running the Windows 2000 Operating System.

Insert the Bluetooth Product CD into your CDROM drive.



Insert the USB Bluetooth Adaptor into an appropriate port.



Windows 2000 will detect your card and start the **Found New Hardware Wizard**.



Click **Next**



Select **“Search for a suitable driver for my device”**. Click **Next**



Select **CD-ROM drives**. Click **Next**



The Wizard has found the required software. Click **Next**



The software is now installed. Click **Finish**.

The **Found New Hardware** wizard will detect a number of devices on your card and install the drivers for them.



A My Bluetooth devices icon will now appear in the My Computer folder on your desktop. Double clicking on this icon will open the My Bluetooth Devices user interface which will enable you to configure your card and establish connections with other bluetooth enabled devices.

The Brain Boxes Bluetooth icon found in the icon tray on your start bar can also be used to access this user interface.

Full details of the My Bluetooth Devices user interface can be found in the configuration chapter.

Version History

Version	Date	Author	Checked By	Comments
1.0	13/05/2002	Gavin Jewell	Name	Using Beta4